









































































Articolo		pag.										
<b>Viti per calcestruzzo</b>												
<b>VF</b>		CE	50	●	*	●	*	○	*	○	●	○
<b>Fissaggi chimici</b>												
<b>KEM E</b>		CE	53	●	●	●	●	●	*	○	●	○
<b>KEM H</b>		CE	54	●	●	●	●	●	*	○	○	○
<b>KEM V</b>		CE	55	●	●	●	●	●	●	○	*	○
<b>KEM HR</b>		CE	56	●	●	●	●	●	●	○	○	○
<b>KEM HP</b>		CE	57	●	●	●	●	●	●	○	○	○
<b>Fissaggi anti-intrusione</b>												
<b>SAFER-O</b>			96	●	●	●	●	●	●	○	○	○
<b>SAFER VITI</b>			96	●	*	●	*	○	*	○	●	○
<b>FM-X5 SAFER</b>			97	●	●	●	●	●	●	○	○	○
<b>Fissaggi prolungati</b>												
<b>X3</b>		CE	101	●	●	●	●	●	●	○	○	○
<b>FM-X5</b>		CE	107	●	●	●	●	●	●	○	○	○
<b>TUP4</b>			110	●	●	●	●	*	●	○	○	○
<b>TUPP</b>			112	●	●	●	●	*	●	○	○	○
<b>TUP</b>			113	●	●	●	*	*	*	○	○	○
<b>TCS</b>			114	●	●	●	*	○	*	○	○	○
<b>TPF</b>			114	●	●	●	●	●	*	○	○	○
<b>Fissaggi leggeri</b>												
<b>X1 evo</b>			115	●	●	●	●	●	●	●	○	○
<b>X1 evo-L</b>			120	●	●	●	●	●	●	●	○	○
<b>XP</b>			123	●	●	●	●	●	●	●	○	○
<b>FX</b>			124	*	*	*	*	●	●	●	○	○
<b>TMT</b>			125	*	*	*	*	●	●	●	○	○
<b>TSS</b>		CE	126	●	●	●	*	*	*	○	○	○
<b>TBB</b>		CE	127	●	●	●	*	*	*	○	○	○
<b>TPP</b>		CE	128	●	●	●	*	*	*	○	○	○
<b>TTL</b>			129	●	●	●	*	*	*	○	○	○
<b>TBS</b>			129	●	●	●	●	●	*	○	○	○
<b>TU</b>			130	●	●	●	*	*	●	○	○	○
<b>TUG</b>			134	●	●	●	●	●	●	○	○	○
<b>TML</b>			138	○	○	○	○	○	●	*	○	○

**LEGENDA**

● = consigliato

\* = parzialmente consigliato

Articolo		pag.									
<b>Fissaggi per cartongesso</b>											
<b>TRZ</b>		143	○	○	○	○	○	●	●	○	○
<b>Fissaggi per termosanitaria</b>											
<b>C-MAX</b>		153	●	●	*	*	○	*	○	○	○
<b>CPA</b>		154	●	●	*	●	○	●	○	○	○
<b>CPI</b>		155	●	●	*	●	○	●	○	○	○
<b>CFR</b>		156	●	●	●	●	●	●	●	○	○
<b>RAIN</b>		157	●	●	*	●	○	●	○	○	○
<b>FL</b>		162	●	●	*	●	○	●	○	○	○
<b>FLB</b>		162	●	●	*	●	○	●	○	○	○
<b>FSN</b>		163	●	●	*	*	*	●	○	○	○
<b>FBD</b>		164	●	●	*	●	○	●	○	○	○
<b>MPP</b>		169	●	●	●	●	*	*	○	○	○
<b>MLRS</b>		169	●	●	●	●	*	●	○	○	○
<b>MPR</b>		169	●	●	●	●	*	●	○	○	○
<b>Fissaggi per materiali elettrici</b>											
<b>FSA</b>		174	●	●	●	●	*	●	○	○	○
<b>CTB</b>		175	●	●	●	●	*	●	○	○	○
<b>CTD</b>		175	●	●	●	●	*	●	○	○	○
<b>CTN</b>		176	●	*	●	●	●	*	○	○	○
<b>CTND</b>		176	●	*	●	●	●	*	○	○	○
<b>CTC</b>		CE 178	●	*	●	●	●	●	○	○	○
<b>CFC</b>		179	●	●	●	●	●	●	○	○	○
<b>STC</b>		179	○	○	○	○	○	●	○	●	○
<b>Fissaggi per materiali isolanti</b>											
<b>ISOPLUS II</b>		CE 182	●	●	●	●	○	●	○	○	○
<b>ISOMAX</b>		CE 184	●	●	●	●	○	●	○	○	○
<b>ISOFAST</b>		CE 185	●	●	●	●	○	●	○	○	○
<b>FOX</b>		189						*			

### LEGENDA

● = consigliato

\* = parzialmente consigliato